

AIR 100

USB + BLUETOOTH
SPEAKERPHONE



User Manual



Overview

The portable microphone speaker phone is the high-quality Internet phone conference call device connected with computers and other intelligent devices. It is provided with the latest generation of voice processing algorithm of acoustic echo cancellation and environmental noise reduction. Its voice quality of the call is clear and natural. Its body is light and the device and cable are integrated, which is easy to carry, install and operate. It is suitable for computer internet phone conference call and other application scenarios.

Packing list



Speakerphone



USB Cable



User Manual

Port Details

1. Answer/End Call
2. Bluetooth
3. Mic / Mute
4. Volume Down
5. Volume Up
6. Power Status Indicator
7. Battery Indicator
8. Bluetooth Status indicator
9. On/ Off button
10. USB Port
11. Line In/Out



LED Status Indicator	Blue Light On	USB Connection
	Red Light On	Microphone Mute Status
Speaker Mute Indicator	Red Light On	Speaker Mute Status
Volume Status Indicator	Green Light On	Current Volume Status
Wireless Indicator	Green Light Off	Wireless Disconnection
	Green Light Always On	Wireless Connection
Battery Indicator	Red Light On	Low Battery
	Green Light Flashing	The Battery is Charging
	Light Off	Full Battery
Microphone Status Indicator	Red Light On	Microphone Mute Status
	Green Light On	Exit Microphone Mute Status

Device connection



1. Application of wired connection of USB interface:

1.1 After the wired connection of USB of the host is successful, the instant messaging or Internet phone application software in the computer can be used. The Internet phone conference can be carried out according to the operation method of the application software.

1.2 Speaker volume adjustment: during a call, press the "Volume decrease" key of the host to gradually decrease the speaker volume to the minimum (Continuous flashing green light means mute speaker); and press the "Volume increase" key to gradually increase the speaker volume to the maximum.

1.3 Microphone pickup and mute: during a call, the microphone is in the pickup state by default. when press the "Microphone mute" key of the host, the status indicator will be red, indicating That the microphone is mute. Press this key again to turn off the red, indicating that the microphone pickup is restored.

2. Application of Bluetooth wireless connection (only applicable to Bluetooth

version):

- 2.1 After the Bluetooth wireless connection of the host is successful, the instant messaging or Internet phone application software in the computer can be used. The Internet phone conference can be carried out according to the operation method of the application software.
- 2.2 When the host is connected with the mobile phone through Bluetooth, in addition to the normal calling, answering or ending of call with the mobile phone, it can also short press the "Power ON /OFF" key of the host to answer the incoming call or long press the "Power ON /OFF" key of the host to end a call.
- 2.3 Speaker volume adjustment: during a call, press the "Volume decrease" key of the host to gradually decrease the speaker volume to the minimum (Continuous flashing green light means mute speaker); and press the Volume increase key to gradually increase the speaker volume to the maximum.
- 2.4 Microphone pickup and mute: during a call, the microphone is in the pickup state by default. When press the "Microphone mute" key of the host, the status indicator will be red, indicating that the microphone is mute. Press this key again to turn off the red indicating that the microphone pickup is restored.
- 2.5 When the status indicator flashes in orange, it will keep reminding you that the built-in battery is low. Please plug it into the USB power port for charging.
- 2.6 When charging, the indicator will be red, and when the built-in battery is fully charged, the red will go out.
- 2.7 Bluetooth connection is preferred when both of USB wired connection and Bluetooth wireless connection are available.

Points for attention

1. You can't connect multiple Cameras or Speakerphones to the computer intelligent device at the same time, including the native device, or else, a squeak may appear during the call.
2. It is required to connect the USB cable directly to the USB interface of the computer device. It may cause operation problems if it is connected through the USB hub.
3. Check whether the device driver is installed and connected successfully: check whether the default device displays "native device model" in the options of playback (output) and recording (input) of the sound and audio device properties of the computer control panel option, if not, re-select "Native device model" and confirm.
4. When use, it can adjust the volume through the speaker option on the computer if necessary. When using instant messaging or Internet phone application software, please set the device of the model as the preferred audio device. Do not repair the device by yourself, or else, it may cause electric shock. Please contact your seller if there is any problem needing repair.

Manufactured in India by



A&T Video Networks Private Limited ®

Service and Support:
support@atnetindia.net
1800-425-5847