


AIR 500


Speakerphone

User Manual




EXPERIENCE **next**


Product Information



Top View



Side View



Bottom View

01. Bluetooth

02. Answer & Hang

03. Volume down

04. Volume up

05. MIC ON/OFF

06. Speaker

07. MIC hole * 8

08. Type-C (IN)

09. Type-C (OUT)


10. DC IN (Power supply)

Warm reminder :

- ① Please use the standard adapter for power supply. Otherwise, it may be damaged or cannot be used normally.
- ② This device has its own audio AI algorithm. To avoid affecting the use effect, disable the echo cancellation, automatic adjustment of microphone volume, and noise reduction functions of the conference software.

Operation instruction

Host connection and multiple cascades



2

Step 1: Plug the first speakerphone into the power adapter for power supply


Step 2: Connect every Speakerphone through cascade cables

Step 3: Connect the first speakerphone to the PC


- ① Support PC, IFP, Smartphone, PAD etc. host devices connect
- ② Can be connect through USB cable, USB dongle and Bluetooth USB cable and USB dongle have the best transfer quality

Cable winding mode on the bottom

Method 1: Cable out on both sides



Method 2: Cable out unilaterally at the top



Note:

You can choose any winding mode according to the actual scenario to ensure the beauty and convenience.

Function description

Answer/Hang up

When a call comes in, press the " " button to answer the call,
long press 2s to reject

When in talking state, long press the " " button 2s to hang up the call
Open/close microphone

Short press the microphone key to open or close the microphone.
The red light indicates that the microphone is off, white light indicates that
the microphone is on (Available only when the speakerphone is in microphone operation).

Volume adjustment

Press "+" or press "-" button to adjust volume, LED ring can be indicates
the volume level

Bluetooth connect

Long press the Bluetooth button for 2s to turn on Bluetooth and enter
the pairing mode. At this time, the Bluetooth light blinks. After the connection,
the Bluetooth light is bright blue

USB Dongle Connect

When the USB dongle is inserted into the USB port of a host device(e.g. PC),
the USB dongle enters the pairing state and the USB dongle indicator blinks
Long press the speakerphone Bluetooth button for 9s, and the speakerphone
enters the dongle pairing state After the pairing is successful, the USB Dongle
indicator is stayed on

Package content

Cascade package :



Speakerphone



USB dongle×1



Power adapter×1



USB cable (A to C) ×1

Important information

This manual records the precautions and product usage methods.
Please read and understand all the instructions before using the equipment.
The damage caused by failure to comply with the instructions is not covered by the warranty.

Maintenance & servicing

1. Please contact professional service personnel for all repair services.
2. Please do not insert any sharp object into the inside of the device.
3. Please do not drop or hit the device to avoid damaging it.
4. This device has a built-in lithium battery, please charge it regularly, otherwise the battery will not be able to continue to be charged and used if it is not charged for a long time.

Statement

1. This manual is for reference only, and the actual function of the final product is subject to the actual function of the product received by the customer.
2. The picture is for reference only, please refer to the actual product.
The company reserves the right to improve and change the appearance and design of the product without notice.

Manufactured in India by



A&T Video Networks Private Limited ®

Service and Support:

support@atnetindia.net
1800-425-5847