



IKON 300



4K All in one Video Soundbar

User Manual



EXPERIENCE NEXT

Overview



No.	Interface/ Component	No.	Interface/ Component
1	LED Light	5	Ethernet
2	Camera Lens	6	EXT(connect with external microphone)
3	Bracket	7	Power(DC12V)
4	USB Type B	8	Service

Packing List



Camera X1



DC Adapter X1




Remote Control X1



USB Cable X 1




Bracket X 2



**TV Mount Bar with
Screws X1**

Camera Remote Control



No.	Name	Function
1	Privacy	Turn on / off privacy protection
2	Auto Framing	Turn on / off Auto framing
3	Pan	➤ In menu mode, set menu options ➤ In non-menu mode, pan right / left
4	Volume	Increase / decrease volume
5	Menu	Open / close the OSD menu
6	Mute	Turn on / off the microphone sound
7	Speaker Tracking	Turn on / off the speaker tracking
8	Tilt	➤ In menu mode, set menu options ➤ In non-menu mode, tilt up / down
9	HOME	➤ In menu mode, confirm to Enter ➤ In non-menu mode, press to move camera to Home position ➤ Long press Home button to switch between USB and Bluetooth audio
10	Zoom	Zoom in / out
11	Number	➤ Short press to CALL saved preset ➤ Long press(2 seconds) to set preset

Features

EPTZ

The camera supports EPTZ control, and 5x digital zoom. The EPTZ can be controlled via direction keys to adjust the image position. And the current image size can be adjusted via zoom button.

Auto Framing

This product has auto framing function. Press the corresponding key and the camera screen can be intelligently scaled according to the number of people in the meeting scene, and centralize all participants. Press again to turn off the auto framing.

Speaker Tracking

The all-in-one supports Speaker Tracking function. Press the Speaker Tracking button to turn on / off the Speaker Tracking function. The all-in-one will give the person who is speaking a close-up view under the Speaker Tracking ON state.

Set/Call The Preset

Long press (2 seconds) the number buttons to set preset;

Short press the number buttons to CALL saved preset, and the camera will quickly go to saved preset position.

Menu Function

After entering the menu, select the menu options via direction keys.

Press the HOME key to enter the options, adjust the options by using the pan button.

Press the Menu key to return to previous menu until the exit menu.

Built-in USB to network adapter

The all-in-one has a built-in USB network adapter. After connecting the network cable to the camera, the computer connect to the camera can access the network through the USB cable without connecting other network cables. Only one USB cable can realize the synchronous transmission of audio, video and network, eliminating the trouble of multiple wiring.

USB And Bluetooth Switching Instructions

After the camera is connected to the USB cable and powered on, the default is USB mode. Long press the HOME key for 2 seconds, the sound source of the horn is switched to Bluetooth, and the word "BT" is displayed on the screen for 5 seconds. Bluetooth is visible and automatically connected to the device (pairing connection is required for the first time).Bluetooth name: 4K Tracking Soundbar.

In Bluetooth mode, long press the HOME key for 2 seconds, the Bluetooth is disconnected, the screen displays the word "USB" for 5 seconds, the sound source of the speaker is switched to USB, and the Bluetooth is invisible and cannot be connected.

Indicator

Action	Indicator Status
Power on, video disable	Green
Power on, video enable	Blue
Mic Mute	Red
Adjust The Volume	Green, the range of light on varies with the volume

Points for Attention

1. You can't connect multiple Cameras to the computer or intelligent device at the same time, including the native device, or else a squeak may appear during the call.
2. It is required to connect the USB cable directly to the USB interface of the computer device. It may cause operation problems if it is connected through the USB hub.
3. Check whether the device driver is installed and connected successfully: check whether the default device displays "native device model" in the options of playback (output) and recording (input) of the sound and audio device properties of the computer control panel option, if not, re-select "Native device model" and confirm.
4. When use, it can adjust the volume through the speaker option on the computer if necessary. When using instant messaging or Internet phone application software, please set the device of the model as the preferred audio device.
5. Do not repair the device by yourself or else it may cause electric shock. Please contact your seller if there is any problem needing repair.

Service and Support:

support@atnetindia.net
1800-425-5847

Manufactured in India by



A&T Video Networks Private Limited ®