


PTC SERIES

Professional PTZ Camera

User Manual



EXPERIENCE **next**

Overview

Video conferencing is a live video-based meeting between two or more people in different locations using video-enabled devices. Video conferencing allows multiple people to meet and collaborate face to face long distance by transmitting audio, video, text and presentations in real time through the internet.

The Video Conferencing System is the high-quality Video conference call device connected with computers and other intelligent devices. It is provided with the latest generation Video processing algorithm of Low light correction, Auto Focus, Acoustic echo cancellation and environmental noise reduction.

The body of this Video Conferencing Camera is light and voice quality of the call is clear and natural. The device and cable are integrated in such a way that it is very easy to carry, install and operate. It is suitable for computer internet phone conference call and other application scenarios.

Packing List



PTZ Camera 1



Power Adapter 1



Remote
Controller 1

RS-232 Control Cable 1



USB Cable 1



Features

Full HD 1080P Resolution

1 / 2.8 Inch Image Sensor with 2MP Lens

72.5° / 59.5° Wide Field of View

12X / 20X Optical Zoom

±170° PAN to cover entire Room

USB, HDMI, & IP Interfaces

RS232 IN / OUT


IR Remote for Easy Control

Device Connection


Connect USB data cable:

Insert the USB cable of the Camera into the USB interface of computer and the driver will be installed automatically. After installation, the computer screen will prompt that it is ready or the device can be used. At this time, the host green indicator is always ON, indicating that it has been connected.

NO.	Interface	NO.	Interface
1	Camera Module	8	Reserved
2	Infrared Receiving Sensor	9	Ethernet
3	Power Indicator Light	10	RS232-IN
4	Communication Indicator light	11	RS232-OUT
5	HDMI	12	Power (DC12V)
6	USB 2.0	13	Mounting Holes (depth 6mm, $\phi 5\text{mm}$)
7	Audio Input	14	Location Hole (depth 5-7mm, 1/4-20UNC)



Remote Control



How to Operate

Application of wired connection of USB interface

Once the wired connection of USB of PTZ Camera is successful, the Video conference systems application software in the computer can be used to establish video conference. The Video conference can be carried out according to the operation method of the application software.

Full HD PTZ Camera using IR Remote control can control Zoom IN/OUT, PAN & Tilt Movement, Setting preset positions of the camera and other setting parameters.

Points for Attention

1. You can't connect multiple Cameras to the computer or intelligent device at the same time, including the native device, or else a squeak may appear during the call.
2. It is required to connect the USB cable directly to the USB interface of the computer device. It may cause operation problems if it is connected through the USB hub.
3. Check whether the device driver is installed and connected successfully: check whether the default device displays "native device model" in the options of playback (output) and recording (input) of the sound and audio device properties of the computer control panel option, if not, re-select "Native device model" and confirm.
4. When use, it can adjust the volume through the speaker option on the computer if necessary. When using instant messaging or Internet phone application software, please set the device of the model as the preferred audio device.
5. Do not repair the device by yourself or else it may cause electric shock. Please contact your seller if there is any problem needing repair.

Service and Support:
support@atnetindia.net
1800-425-5847

Manufactured in India by



A&T Video Networks Private Limited ®